


LT50/LTM50-CB



Link Welding Technology Co., Limited

Add: Rm. 19C, Lockhart Ctr., 301-307 Lockhart Rd., Wan Chai, Hong Kong.

Tel: +00852-6735 8659 Fax: +00852-3114 9072 Email: info@linkwelding.com



HAND TORCH

Code	Ref	Description
IVT6800	1526	Plasma cutting torch LT50/6m 1/8G; 等离子切割枪/LT50/6m 1/8G
IVT6805		Plasma cutting torch LT50/6m 1/4G; 等离子切割枪/LT50/6m 1/4G
IVT6806		Plasma cutting torch LT50/6m M14×1; 等离子切割枪/LT50/6m/M14×1
IVT6809		Plasma cutting torch LT50/6m M16×1.5; 等离子切割枪/LT50/6m/M16×1.5
IVT6807	1574	Plasma cutting torch LT50/6m central adaptor; 等离子切割枪/LT50/6m/中央插头

MACHINE TORCH

Code	Ref	Description
IVT6730		Plasma cutting auto torch LTM50/6m 1/8G; 等离子自动切割枪/LTM50/6m 1/8G
IVT6722		Plasma cutting auto torch LTM50/6m 1/4G; 等离子自动切割枪/LTM50/6m 1/4G
IVT6723		Plasma cutting auto torch LTM50/6m M14×1; 等离子自动切割枪/LTM50/6m/M14×1
IVT6724		Plasma cutting auto torch LTM50/6m M16×1.5; 等离子自动切割枪/LTM50/6m/M16×1.5
IVT6736		Plasma cutting auto torch LTM50/6m central adaptor; 等离子自动切割枪/LTM50/6m/中央插头

Position	Code	Ref	Description
1	ISM0603		SPACER SPRING/LT50; 隔离簧/LT50
2	ISM0006		Shield cap for extended tip/LT50; 长 接触切割保护帽/LT50
3			Outside nozzle; 外 喷嘴
3.1	IVS0008-03	5.710.121	Outside nozzle LT50; 外 喷嘴 LT50
3.2	IVS0008-01		Outside nozzle/maximum life LT50; 外 喷嘴/长寿命 LT50
4	IVU0069-10	1306	Extended conical tip Φ 1.0mm/LT50; 加 长锥形喷嘴 Φ 1.0mm/LT50
5			Extended tip; 加 长喷嘴
5.1	IVU0019-10	1370	Extended tip Φ 1.0mm/LT50; 加 长喷嘴 Φ 1.0mm/LT50
5.2	IVU0018-10	1395	Extended tip Φ 1.0mm/LT50-70; 加 长喷嘴 Φ 1.0mm/LT50-70
5.3	IVU0018-11		Extended tip Φ 1.1mm/LT50-70; 加 长喷嘴 Φ 1.1mm/LT50-70
6	IVU0064-10	1305	Conical tip Φ 1.0mm/LT50-70; 锥形喷嘴 Φ 1.0mm/LT50-70
7			Tip; 喷嘴
7.1	IVU0033-10	1396	Tip Φ 1.0mm/LT50-70; 喷嘴 Φ 1.0mm/LT50-70
7.2	IVU0033-11		Tip Φ 1.1mm/LT50-70; 喷嘴 Φ 1.1mm/LT50-70
7.3	IVU0033-12		Tip Φ 1.2mm/LT50-70; 喷嘴 Φ 1.2mm/LT50-70
7.4	IVU0065-10	1304	Tip Φ 1.0mm/LT50-70; 喷嘴 Φ 1.0mm/LT50-70
8	IVF0002		Diffuser LT50-70; 分 流器 LT50-70
9	IVB0015	1518-HF	Extended electrode HF Plasma LT50; 加 长等 离子电极/HF/LT50
10	IVB0062	1521-HF	Electrode HF Plasma LT50; 等 离子电极/HF/LT50
11	IVZ0050		Plasma torch head LT50; 等 离子枪头 LT50
11a	IFT0707		* O'ring Φ 12.42×1.78mm in silicon red; O型圈 Φ 12.42×1.78mm/硅胶/红色
12	IGV0039		Plasma handle manual/CB50-70/Red; 等 离子手工手柄/CB50-70/红色
13	IHJ0722		Protection part/Plasma/Yellow; 开 关保护档片/等 离子用/黄色
14	IHQ0070	185.0031	Trigger; 开 关
15	IHJ0893		Joint/small/new type; 球 节零件/小/新式
16			Cable assembly; 电 缆组
16.1	IVN00006066-00		Cable assembly/LT50-70/6MMQ/6M ATT. 1/8G; 电 缆组/LT50-70/6MMQ/6M ATT. 1/8G
16.2	IVN00006060-00		Cable assembly/LT50-70/6MMQ/6M CENTER ADAPTOR; 电 缆组/LT50-70/6MMQ/6M 中央插头
16.3	IVN10006060-00		Cable assembly/LTM50-70/6MMQ/6M CENTER ADAPTOR; 电 缆组/LTM50-70/6MMQ/6M 中央插头
16.4	IVN10006060-00		Cable assembly/LTM50-70/6MMQ/6M ATT. 1/8G; 电 缆组/LTM50-70/6MMQ/6M ATT. 1/8G
16.5	IVN0628		Cable assembly LT50-70/6m central adaptor; 电 缆组 LT50-70/6m/中央插头
17	ICG6006		Spanner for Plasma; 等 离子枪扳手
18	IVZ0085		Plasma torch head LTM50; 等 离子枪头 LTM50
18a	IGV0013	W0 300144	Fiber glass position tube/LTM; 自动枪手柄 LTM
19			Cable assembly LTM; 电 缆组 LTM
19.1	IZT5687		Connecting adaptor 1/8G-1/4G; 转换接头 1/8G-1/4G
19.2	IZT5688		Connecting adaptor 1/8G-M14×1; 转换接头 1/8G-M14×1
19.3	IZT5689		Connecting adaptor 1/8G-M16×1.5; 转换接头 1/8G-M16×1.5
20	IZX0078		Central adaptor torch side Plasma 5 pins; 等 离子中央插头/5针
21	ISM0081	166	Circle cutting attachment/LT50; 圆 周切割附件 LT50

Link Welding Technology Co., Limited

Add: Rm. 19C, Lockhart Ctr., 301-307 Lockhart Rd., Wan Chai, Hong Kong.

Tel: +00852-6735 8659 Fax: +00852-3114 9072 Email: info@linkwelding.com